

Allergan 30 kW Photovoltaic (PV) Solar Power System

In 2006, Allergan contracted with SPG Solar to design and install a 30 kW solar power system as a pilot project to further solar power installation project at all Allergan facilities. Allergan installed the system in 2006 and the system was operational in 2007.

The system consists of 168 208 watt polycrystalline PV modules and one Xantrex 30 kW power inverter. The PV modules are mounted on a non-penetrating rooftop mounting system.



The modules are oriented toward the south at a 5 degree angle and are fixed in position. Allergan also installed a Kiosk system so that the performance of the PV system could be viewed by Allergan employees.



Allergan is currently evaluating the system to determine its delivery on promised performance and where it might make sense to install more and larger systems.

